

TrailerSaver, LLC

112 Lakeshore Drive
Hardinsburg, KY 40143

"The name says it all"

(270) 779-9182

INSTALLATION PROCEDURES FOR DVI RIDE STABILIZERS ON AIR RIDE SEATS

Enclosed are the DVI Ride Stabilizers for air seats with a short piece of tubing installed in one end. Remove the tubing from the air fitting that is on your air spring by pulling the collar that is on the fitting towards the fitting while at the same time pulling the tubing out of the fitting. Install the Ride Stabilizer with the short piece of tubing into the air fitting by pushing the tubing into the fitting until it bottoms out and then re-install the air line into the open end of the Ride Stabilizer.

If your seats do not have the quick disconnect fitting they will have a barbed fitting installed. If this is the case you will need to cut the tubing 3/4" from the end of the barb fitting. Remove the short piece of tubing that came installed in your stabilizer and install the DVI Ride Stabilizer onto the cut tubing and install the other end of the tubing into the other end of the stabilizer. These units are non-directional.

These units come in sizes 4,5,6, and 7. The lower the number, the tighter the control. For example, if you are medium height and light weight, the "7" will give you a nice bit of control. The "4" will ride way too hard. The shorter that you are, the tighter control that you will need. And, the heavier that you are, the tighter the control that you will need.

These devices will enable you to run with the seat positioned lower without bottoming out. For real tall people, we also see less tossing of your head into the roof.

Thanks,

Steve Dabbs